

## Bringing Projects Back onto Your Recon (Mobile DLog)

- Go to your Recon and open, Mobile Dlog
- Click on **Menu> File> New Project**
- Give your project coordinates\* and click **OK**
  - \* The coordinates that are in there will work, if blank then obtain coordinates from the Project in ViewPoint
- Give your project a name (be sure not to give it the same name as before example: old name "farmer" new name "Farmer 07") and click **OK**
- Now Exit Mobile Dlog by going **Menu** then **Exit**.
- Now On your Desktop Computer make sure that you Recon is connected.
- Go to where your raw data is saved (C:/ Tile Maps)
- Open up the project that you want to bring back onto your Ipaq.

\* Only **DDS\_LOG** files can be brought back NO **DDS\_LPF** or **DDS\_PPF** files  
Example Boundary.dds\_log, 5 in.dds\_log, riser.dds\_log.

- While holding down the Control Key (Ctrl) left click on the layers that you want to bring back.
- Now that they are all highlighted blue, right-click on one of the blue files and then click **Copy**.
- Open Microsoft Active Sync.
- Left click on **Explore**,
- Find your project that you just created ("Farmer 07") and double left-click on that project.
- Now right click in the white area and click on **Paste**.
- Now on the Recon Open Mobile Dlog
- Open your new Project and then click on the re-center button .
- You should now be able to see your project.