


Bringing Projects Back onto Your Recon (Pocket DLog)

- Go to your Recon and open, Pocket Dlog
- Click on **File**, then **New Project**
- Give your project coordinates* and click **OK**
 - * The coordinates that are in there will work, if blank then obtain coordinates from the Project in ViewPoint
- Give your project a name (be sure not to give it the same name as before example: old name "farmer" new name "Farmer 07") and click **OK**
- Now Exit Pocket Dlog by going **File** then **Exit**.
- Now On your Desktop Computer make sure that you Recon is connected.
- Go to where your raw data is saved (C:/ Tile Maps)
- Open up the project that you want to bring back onto your Ipaq.

* Only **DDS_LOG** files can be brought back NO **DDS_LPF** or **DDS_PPF** files
Example Boundary.dds_log, 5 in.dds_log, riser.dds_log.

- While holding down the Control Key (Ctrl) left click on the layers that you want to bring back.
- Now that they are all highlighted blue, right-click on one of the blue files and then click **Copy**.
- Open Microsoft Active Sync.
- Left click on **Explore**,
- Double Left Click on **My Windows Mobile Based Device**
- Double Left Click on **Built-In Storage**
- Double Left Click on **LOGPROJECTS**
- Find your project that you just created ("farmer 07") and double left-click on that project.

- Now right click in the white area and click on **Paste**.
- Now on the Recon Open Pocket Dialog
- Select your new Project out of your project list, and then click on the re-center button .
- You should now be able to see your project.